

HOW TO REPAIR CORD SLACK ON AKZ CANTILEVER

STEP 1

Turn light adapter counter-clockwise and pull down from hub (Fig. 1). Remove 2 screws from light adapter using a Phillips screwdriver. Set screws and light adapter cap aside.



(Fig. 1)

STEP 2

Have a second person helper open ribs slightly open so that you are able to grab the cord located inside the hub and pull cord down (Fig. 2). Untie cord from cord lock and remove. If spring is not visible, it may be stuck inside hub. Reach inside hub with your finger and pull spring down, remove from cord and set aside (Fig. 3). Pull cord down, until cord is tight and there is no slack (Fig. 4).



(Fig. 2)



(Fig. 3)



(Fig. 4)

STEP 3

Measure 3 1/2" of cord from hub (Fig. 5) and cut off remaining cord (Fig. 6). To keep cord from fraying any further, use a lighter or match to light end of cord for a quick second (Fig. 7), blow out and use your fingers to taper end strings together.



(Fig. 5)



(Fig. 6)



(Fig. 7)

STEP 4

Pull cord out from light adapter hub, put spring back on cord (Fig. 8) and put cord through hole of cord lock (Fig. 9). Give 6 1/2" of cord through hole (Fig. 10). Wrap cord around one side of cord lock (Fig. 11) and up straight on the other side (Fig. 12). Bring spring back down cord and put extra cord through spring and tighten spring onto cord lock (Fig. 13).



(Fig. 8)



(Fig. 9)



(Fig. 10)



(Fig. 11)



(Fig. 12)



(Fig. 13)

STEP 5

Let cord go back into light adapter hub (Fig. 14). Second helper person can now gently let go of ribs.



(Fig. 14)

STEP 6

Place light adapter cap back onto light adapter and secure with 2 screws (Fig. 15).



(Fig. 15)

